

SURP Week 5

Continued Parameter Calculation


Collimator

Collimator input is direct output from DMD after relay optics, so

$$F/\#_{\text{col}} = F/\#_{\text{relay}} = \boxed{4.53}$$

$$f_{\text{col}} = F/\#_{\text{col}} D_{\text{col}} \quad \text{Need to know lens size}$$

Using DMD size to estimate minimum lens size



$$D_{\text{col}} = \sqrt{2(13.7)^2}$$

$$f_{\text{col}} = F/\#_{\text{col}} D_{\text{col}}$$

$$= (4.53) (\sqrt{2(13.7)^2})$$

$$= \boxed{87.71 \text{ mm}}$$

Magnification of Spectrograph

The magnification can be found using the ratio between sensor and DMD height

$$M_{\text{spec}} = \frac{Y_{\text{sensor}}}{Y_{\text{DMD}}} = \frac{(.0137)(1000)}{(.006)(2000)} = \boxed{.88}$$