

SURP Week 5

Continued Parameter Calculation


Collimator

Collimator input is direct output from DMD after relay optics, so

$$F/\#_{\text{col}} = F/\#_{\text{relay}} = \boxed{4.53}$$

$$f_{\text{col}} = F/\#_{\text{col}} D_{\text{col}} \quad \text{Need to know lens size}$$

Using DMD size to estimate minimum lens size



$$D_{\text{col}} = \sqrt{2(13.7)^2}$$

$$f_{\text{col}} = F/\#_{\text{col}} D_{\text{col}}$$

$$= (4.53) (\sqrt{2(13.7)^2})$$

$$= \boxed{87.71 \text{ mm}}$$

Magnification of Spectrograph

The magnification can be found using the ratio between sensor and DMD height

$$M_{\text{spec}} = \frac{Y_{\text{sensor}}}{Y_{\text{DMD}}} = \frac{(.0137)(1000)}{(.006)(2000)} = \boxed{.88}$$

Camera

First, using collimator f-number and spectrograph magnification to calculate $F/\#_{\text{cam}}$.

$$\begin{aligned} F/\#_{\text{cam}} &= M_{\text{spec}} F/\#_{\text{col}} \\ &= (0.88)(4.53) = \boxed{3.97} \end{aligned}$$

Assuming the camera lens is the same size as the collimator

$$\begin{aligned} f_{\text{cam}} &= M_{\text{spec}} f_{\text{col}} = (0.88)(87.71) \\ &= \boxed{76.82 \text{ mm}} \end{aligned}$$

Number of pixels for one micro-mirror

This can be found by using the plate scale constants for the DMD and detector

$$P_{\text{DMD}} = 1.50'' \quad P_{\text{sensor}} = .75''$$

$$W'_{\text{DMD}} = \frac{A_{\text{FOV}}}{P_{\text{DMD}}} = \frac{A_{\text{FOV}}}{1.50''} \quad W'_{\text{sensor}} = \frac{A_{\text{FOV}}}{P_{\text{sensor}}} = \frac{A_{\text{FOV}}}{.75''}$$

$$\Rightarrow W'_{\text{sensor}} = 2W'_{\text{DMD}} \Rightarrow \boxed{2 \text{ pixels for 1 micro-mirror}}$$

Micromirrors per slit and pixels per slit

Assuming the telescope focussed light directly to the DMD, we could use

$\omega = \phi f_{tel}$ where ϕ is the angular slit width width equal to seeing resolution ($\phi = 3''$)

$$\text{Then, } N_{\text{mirrors}} = \frac{\omega}{(.0137\text{mm})}$$

for the number of pixels per slit,

$$\omega' = \omega \left(\frac{f_{cam}}{f_{tel}} \right), \quad N_{\text{pixels}} = \frac{\omega'}{(.006\text{mm})}$$

However I am unsure how the relay optics changes the first step.

Diffraction angle and groove density

These are related by

$$\frac{1}{N} \sin \theta = \lambda, \text{ however } N \text{ and } \theta$$

so far are both unknown,

My guess is to approximate that

$$\theta \approx \arctan\left(\frac{w'}{f_{\text{cam}}}\right)$$

then solve for N with

$$N = \frac{\sin \theta}{\lambda} \quad \text{where } \lambda = 0.55 \mu\text{m}$$